

CEVO-care P-6211



Glossy surface



Easily dispersable



Protection



Viscosity-regulating

WAX ADDITIVE FOR SOLVENT-BORNE DISPERSIONS



CEVO-care P-6211

Characterisation

CEVO-care P-6211 is a high-melting, hard special wax. It is used as a wax dispersion for solvent-based polishes and coatings.

Typical data and properties			
Acid value *	10 – 14 mg KOH/g	Saponification value *	17 – 25 mg KOH/g
Drop point *	104 – 112 °C	Solidification point	93 – 99 °C
Colour	almost white, ivory-coloured	Viscosity	90 – 120 mPas; 120 °C
Physical form	flakes or pastilles	Density	< 1 g/cm ³
Packing	paper bag	Penetration value	approx. 4 dmm

* Delivery specification

Solubility

CEVO-care P-6211 is insoluble or only very sparingly soluble in all conventional organic solvents at room temperature. It is soluble at elevated temperatures in aliphatic, aromatic and chlorinated hydrocarbons and most other solvents that are not too polar.

The following table shows the temperature at which CEVO-care P-6211 forms a clear 10 % solution in selected solvents (clear point). The cloud point is the temperature at which dissolved solids are no longer completely soluble, precipitating as a second phase giving the fluid a cloudy appearance.

Solvent	Clear point [°C]	Cloud point [°C]
Petrol 100/140 °C	approx. 76	approx. 71
White mineral spirits 140/200 °C	approx. 79	approx. 72
Toluene	approx. 73	approx. 66
Shellsol A	approx. 75	approx. 66

Compatibility

CEVO-care P-6211 can be blended with many other type of waxes like paraffin, microcrystalline wax, polyethylene wax and ester wax (e.g. montan-, carnauba-, beeswax) simply by melting and stirring them together.





APPLICATION

General

Depending from the concentration, clear solutions of CEVO-care P-6211 in hot organic solvents crystallise to form very finely divided liquid dispersions, gels or pastes when the heated solution is cooled under stirring. The received wax preparations have a very slight solvent retention when the wax dispersion is dried. On a surface they form very dense, buffable films.

To manufacture the wax pastes, CEVO-care P-6211 alone or with other waxes and components are blended together at approx. 110 °C. The solvent, which can also contain dissolved silicon oil and other substances, is then added. At this stage, a clear solution must be produced.

The temperature during the mixing process should be in the region of 75 – 80 °C. In the manufacture of fine and low-viscosity wax dispersions (e.g. for floor polish) with CEVO-care P-6211 it is important to cool down the clear solution of the wax in the solvent as quickly as possible whilst stirring vigorously (water cooling). A further improvement in the fineness of the particles is provided by subsequent brief homogenisation with a high-speed stirrer (e.g. Ultra-Turrax).

To obtain fine, softer creamier pastes or gels, the mixture is cooled down, until clouding clearly starts to occur (pouring temperature) and is poured out, e.g. into tins.

Polishes

Very finely divided, liquid wax dispersions can be prepared that dry to form a very glossy and dense, easy to polish film. This is very important for polishes applied to floors and car bodywork or other substrates (other metal surfaces, furniture, parquet), which require a good film formation. The a.m. films are impermeable to air, corrosive gases, water, salt solutions, acids, alkalis, coolant and other aggressive substances. The wax film can be removed easily and completely with cold cleaning agents based on organic solvents (aliphatic hydrocarbons) and surfactants. Steam jet cleaning also works very well. The consistency of the wax preparation can be controlled by adjusting the proportion of CEVO-care P-6211 and the different waxes employed or by adjusting the total wax content.

Base formulations

Base formulations for the most important polish applications are suggested in the following tables (1 – 3). Partly they are tested successfully in practice and partly successfully in the laboratory and should inspire for further developments.



BASE FORMULATIONS

Formulation no	1	2	3	4
Physical form	Liquid	Liquid	Liquid	Soft paste for tube packaging
Solid content in % w/w	12	12	15	27
Components	(All figures in % w/w)	(All figures in % w/w)	(All figures in % w/w)	(All figures in % w/w)
CEVO-care P-6211	3.5	6.0	4.0	1.5
WARADUR® E	-	-	-	0.5
Luwx® A	-	-	-	4.5
Hard microcrystalline wax Fp = 85 – 92 °C	2.0	-	3.0	3.0
Soft microcrystalline wax Fp = 65 – 72 °C	2.0	-	-	-
Paraffin wax 52/54 °C	4.5	6.0	8.0	17.5
White spirit 140/200 °C	88.0	88.0	85.0	73.0

Table 1: Liquid/soft formulations, e.g. for floor polishes

Formulation no	5	6	7	8
Application	Car	Car	Furniture and parquetry	Shoe
Physical form	Liquid	Liquid	Liquid	Soft paste for tubes
Solid content in % w/w	7	29	7	23
Components	(All figures in % w/w)	(All figures in % w/w)	(All figures in % w/w)	(All figures in % w/w)
CEVO-care P-6211	3.8	2.0	2.0	1.0
WARADUR® OP	-	-	-	2.0
WARADUR® E	-	0.5	-	-
Luwx® A	-	4.5	-	4.0
Hard microcrystalline wax Fp = 85 – 92 °C	-	3.0	0.5	-
Soft microcrystalline wax Fp = 65 – 72 °C	-	-	1.5	2.0
Paraffin wax 52/54 °C	-	17.0	1.5	14.0
Silicon oil 350 mm ² /s	0.6	2.0	-	-
Wacker silicon paste P 8	-	-	1.5	-
XIAMETER™ OFX-0531 Fluid	2.6	-	-	-
Petrol 100/140 °C	63.0	-	43.0	-
White spirit 140/200 °C	30.0	71.0	50.0	77.0

Table 2: Polishes for car care, furniture, shoe polish and parquetry

Formulation no	9	10	11	12
Physical form	Highly liquid	Highly liquid	Soft paste	Hard paste
Solid content in % w/w	5	10	30	30
Components	(All figures in % w/w)	(All figures in % w/w)	(All figures in % w/w)	(All figures in % w/w)
CEVO-care P-6211	2.0	4.0	5.0	10.0
Hard microcrystalline wax Fp = 85 – 92 °C	-	-	5.0	10.0
Soft microcrystalline wax Fp = 65 – 72 °C	1.0	2.0	-	-
Paraffin wax 52/54 °C	1.5	3.0	20.0	-
Paraffin wax 60/62 °C	-	-	-	10.0
Silicon oil 350 mm ² /s	0.5	1.0	-	-
Petrol 100/140 °C	50.0	50.0	-	-
White spirit 140/200 °C	45.0	40.0	70.0	70.0

Table 3: Formulations with different consistencies for various applications

PRODUCT INFORMATION

CEVO-care P-6211

Product Description

CEVO-care P-6211 is a special wax blend, based on polymer waxes, hydrocarbon waxes and stearates.

General Advantages

Depending from the concentration, clear solutions of CEVO-care P-6211 in hot organic solvents crystallise to form very finely divided liquid dispersions, gels or pastes when the heated solution is cooled under stirring. The received wax preparations have a very slightly solvent retention when the wax dispersion is dried. On a surface they form very dense, buffable films.

Examples of Use

- Very finely divided, liquid wax dispersions can be prepared that dry to form a very glossy and dense, easy to polish film. This is very important for polishes applied to floors and car bodywork or other substrates (other surfaces, furniture, parquetry), which requires a good film formation.
- The consistency of the wax dispersion can be adjusted from liquid to pasty by choosing the adequate proportion and concentration of CEVO-care P-6211 and if necessary other additional waxes.
- Technical information brochure available upon request.

Delivery Specifications *

Characteristics	Unit	Target value	Method
Acid value *	mg KOH/g	10 – 14	ISO 2114
Drop point *	mg KOH/g	17 – 25	ISO 3681
Acid value *	°C	104 – 112	ASTM 3954
Colour	–	off white	AA 3.2.1.505
Viscosity @ 120 °C	mPas	90 – 120	AA 3.2.1.520
Colour	g/cm ³	1.00 – 1.02	Ph. Eur. 2.2.5

Packaging and Handling

Physical form	Pastilles
Packaging	Paper bag or Big Bag
Storage	Store at ambient temperature on a dry place. Protect from heat/overheating and direct sunlight. The maximum shelf life is 5 years after production. Thereafter, tests of the chemical characteristics are recommended. After delivery, a minimum remaining shelf life at the customer of 1.5 years is warranted.

Safety

CEVO-care P-6211 is not classified as carcinogenic, mutagenic or reprotoxic; no health or environmental hazards are known, provided it is applied in industrial and professional settings.

For more information, consult SDS.

Delivery Time and Availability

Standard delivery time: 2 – 3 weeks. Preconditions can be met for achieving shorter delivery times on standard products when demanded by the market.

Remark: Voelpker's R&D department is permanently developing new (tailor-made) special wax blends for mould release applications. Please contact us for your individual requirements.

Legislation

Food contact legislation:

- Product for technical applications

Other legislation:

- REACh compliant; all components registered or exempt (polymers, salts of fatty acids)
- RoHS and CONEG compliant
- Ingredients listed in all relevant National Inventories

For further information, please contact application@voelpker.com.

The information contained herein is believed to be accurate and reliable as of the date issued. However, we do not warrant or guarantee the accuracy or reliability, in particular not for any specific intended use by the customer. It is the responsibility of those to whom we supply our products directly or indirectly to ensure that their use of the products complies with existing regulations, laws, legislations and proprietary rights. The information given by Völpker Spezialprodukte does not exempt the customer from carrying out inspections and analyses on goods purchased.

Issued: 2019-01-11, supersedes all previous editions

Völpker Spezialprodukte GmbH · Fabriksstraße 1 · 39393 Völpke · Germany · Telephone +49 39402 962-0 · www.voelpker.com



VOELPKER

Völpker Spezialprodukte GmbH

Fabrikstraße 1 | 39393 Völpke | Germany

Tel. +49 (0) 39402 962-0

Fax +49 (0) 39402 215

mailbox@voelpker.com

www.voelpker.com

Design: www.artfaktor.de

1st edition | February 2019



Disclaimer

The information contained herein is believed to be accurate and reliable as of the date issued. However, we do not warrant or guarantee the accuracy or reliability, in particular not for any specific intended use by the customer. It is the responsibility of those to whom we supply our products directly or indirectly to ensure that their use of the products complies with existing regulations, laws, legislations and proprietary rights. The information given by Völpker Spezialprodukte does not exempt the customer from carrying out inspections and analyses on goods purchased.