

TECHNICAL STUDY





Cycle time reduction



costs



Demolding



THE EFFECT OF WARADUR® OPplus
ON THE NUCLEATION BEHAVIOUR OF PET

Introduction

WARADUR® OPplus is a proprietary formulation based on polar montan ester wax with a particularly high proportion of calcium montante.

In the present study the crystallisation temperature of PET with 0,5 % WARADUR® OPplus has been DSC-analysed in comparison to the non additivated polymer. The aim of the study was to demonstrate a nucleation effect of WARADUR® OPplus by increasing the PET crystallization temperature.



	Target value	Unit	Method
Acid number	< 10	[mg KOH/g]	ISO 2114
Melting range	88-114	[°C]	DSC
Solidification range	92-65	[°C]	DSC
Ca content	3,5 – 5,0	[%]	RFA

Table 1: Characteristics of WARADUR® OPplus

- 1. PET: Lighter C93, unfilled (Equipolymers)
- 2. WARADUR® OPplus (VOELPKER)

Pretreatment of PET: dried at 120 °C / 2,5 h

Test equipment

Injection molding: Arburg Allrounder 320 C 500-170

Temperature profile: 250/265/275/285 °C

Differential Scanning Calometry (DSC): Mettler Modul: 822e/1344/500

Method: PET ASTM D 3410 40-300:

- Dt 0,5 s [1] 40 °C, 5 min [2] 40,0..300 °C, 10,00 K/min
- [3] 300°C, 5 min [4] 300,0 °C..40 °C, -2,00 K/min
- [5] 40,0 °C, 5 min [6] 40,0 °C..300,0 °C, 10 K/min

Results




Table 2: Shift of the DSC Crystallisation temperature PET \rightarrow and PET with WARADUR® OPplus




Table 4: Difference of the DSC Crystallisation temperature PET and PET with WARADUR® OP plus

Nr.	PET/PET Formulation	Solidification temperature [°C]	Solidification temperature Difference [Δ °C]
1	100 % PET	208,9	-
2	99,5 % PET + 0,5 % WARADUR® OP <i>plus</i>	213,7	+ 4,8

Table 3: Formulation and solidification temperature difference

Summary

WARADUR® OP*plus* acts as a suitable nucleating agent in PET. It can enhance the crystallization rate of PET and provide reduced cycle times in injection molding.

WARADUR® OP*plus* is effective at concentrations of 0.1 – 0.5 % in polyester. It exhibits additional desirable

properties for PET injection molding, for example: low volatility and favourable lubrication, mold-release and surface improving effects. WARADUR® OPplus thus contributes to improved PET processing and and final product performance.



Völpker Spezialprodukte GmbH Fabrikstraße 1 | 39393 Völpke | Germany Tel. +49 (0) 394<u>02</u> 962-0 Fax +49 (0) 39402 215 application@voelpker.com www.voelpker.com

Design: www.artfaktor.de



This flyer is printed on certified recycled paper.



EcoVadis has awarded VOELPKER's Corporate Social Responsability



The information contained herein are believed to be accurate and reliable as of the date issued. However, we do not warrant or guarantee the accuracy or reliability, in particular not for any specific intended use by the customer. It is the responsibility of those to whom we supply our products directly or indirectly to ensure that their use of the product complies with existing regulations, laws, legislations and proprietary rights. The information given by Völpker Spezialprodukte does not exempt the customer from carrying out inspections and analyses on goods purchased.